


1.0 ToolVox Software Update


- 1.1 Insert the ToolVox Update CD for your ToolVox edition (Standard or Advanced) into the ToolVox hardware's CD-ROM drive
- 1.2 Browse to the IP address of your ToolVox Communications Server
 - 1.2.1 <http://<IP address of ToolVox>>
 - 1.2.2 Click on “**ToolVox Administration**”



- 1.3 Enter “Username”:
- 1.4 Enter “Password”:
- 1.5



- 1.3 Click on **Tools** next to Setup
- 1.4 Under “System Administration”, click **ToolVox Update**
- 1.5 Click **Update System**.
- 1.6 After updating, you may need to refresh your screen.
- 1.7 Log out and then log back in to ToolVox Communication Manager.



The screenshot displays the ToolVox web interface for system updates. The main content area is titled "ToolVox System Update" and includes the following sections:

- System Version:** ToolVox Standard Edition, Version 1.1.2-1
- Update:** Insert your ToolVox Update CD-ROM into the system drive and press the button below to install updates.
- WARNING:** Make sure you have backed up your system configuration before proceeding!
- Update System:** A button to initiate the update process.

The interface also features a navigation menu on the left, a top header with "Admin / CDR Reports / EMS Records / Help", and a footer with "ToolVox Communications Manager".

- 1.8 The update process is now complete.